

Model #


# 1152GBCH

## Cascade

### 1-Door Chest

#### Glazed Black Cherry finish

*Assembly Instructions*



#### IMPORTANT NOTES:

- For normal household use only. *Not* recommended to use this product in a commercial setting.
- Do not climb, sit or stand on or in this piece of furniture.
- Do not overload the drawers.
- Unload items before you move this unit.
- Before you load or move this unit, tighten all screws and supports.
- Before you begin your project, completely read the Assembly Instructions.
- Store this item: 1- in its box; 2- in a dry place; 3- in temperatures that range from 40°F to 90°F (not on a cold and possibly damp cement floor).
- Periodically inspect your furniture for any loose glue joints, screws or any other problem that might affect the stability of your furniture. Tighten or repair as needed.

#### WARNING

**Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:**

- Place heaviest items in the bottom drawers.
- Unless specifically designed to accommodate, do not set TVs or other heavy objects on top of this product.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time.

**Properly installing tip-over restraints may reduce but does not eliminate the risk of tip-over.**

**DESIGN SUBJECT TO CHANGE WITHOUT NOTICE**

#### **Congratulations!**

*This fine piece of furniture will make a gorgeous addition to your home. For the best results, read the Assembly Instructions before you begin your project.*



**CALL US FIRST! Do not return this item to the store**

**Service Policy:** We will replace any part that is defective, missing or damaged during assembly. For a replacement part, contact Whittier Wood Products customer service department by phone, fax, mail or email.

**Hours:** Our friendly customer service staff can be reached Monday-Friday 7:00 a.m. to 5:00 p.m. (Pacific Time). You may leave a message 24 hours a day, seven days a week.

**To Order:** Provide the furniture model number (upper portion of this page), the part letter, production code, quantity needed, reason for replacement and your full name, address and telephone number.

*Parts ship from our Eugene, Oregon factory within one or two business days from the time we receive your request. Please allow five to ten business days for delivery*

**800-653-3336 • Outside the U.S. or Canada: 541-687-0213 • Fax: 541-687-2060**  
**www.whittierwood.com • P.O. Box 2827 • Eugene, Oregon 97402, U.S.A.**

**Whittier**  
**Wood**  
FURNITURE

P.O. Box 2827  
Eugene, OR 97402 USA

Production Code:



VN

03/12


# 1152GBCH Cascade 1-Door Chest

## Parts List

Please identify the parts and check that quantities received match those on this list.  
If you need to replace a part, refer to the following letter(s) and part name.

Part	Description		Quantity
A	Top Assembly (attached)		1
B	Case		1
C	Adjustable Shelf (installed)		2
D	Door (attached)		1
E	Small Drawer Box (inserted)		5
F	Bottom Drawer Box (inserted)		1
G	Small Drawer Face (installed)		5
H	Bottom Drawer Face (installed)		1
I	Small Pull (attached)		6
J	#8 x 1-1/2" Machine Screw (installed)		10
K	Large Pull (attached)		2
L	#8 x 1-1/4" Machine Screw (installed)		6
M	Drawer Slides (pre-installed sets)		6
N	#6 x 1/2" Philtruss Screw (inserted)		36
O	#6 x 3/4" Philtruss Screw (inserted)		36
P	Insert Nut (inserted)		4
Q	Adjustable Glide (installed)		4
R	#8 x 7/8" Lo-Profile Screw (inserted)		28
S	Shelf Bracket (attached)		8
T	#6 x 1/2" Undercut Screw (inserted)		8
U	Hinge (attached)		2
V	#6 x 5/8" Flat Head Screw (inserted)		12
W	Magnetic Catch Kit (installed)		1 set
X	#6 x 5/8" Philtruss Screw (inserted)		2
Y	#6 x 5/8" Undercut Screw (inserted)		2

**1152GBCH Cascade 1-Door Chest**  
*Parts List*

<b>Part</b>	<b>Description</b>		<b>Quantity</b>
ZA	#8 x 1-1/4" Pan Head Screw (inserted)		25
ZB	#8 x 1-1/4" Black Screw (inserted)		6
ZC	#8 x 1-5/8" Black Screw (inserted)		3
TR	Furniture Tipping Restraint		2 sets

# 1152GBCH Cascade 1-Door Chest

## Assembly Instructions

### Tool Required: Phillips Screwdriver

1. Place the chest at its final destination. Rotate the Adjustable Glides (Q) on the bottoms of the legs until the unit is level. See Figure 1.




Fig. 1

2. To move the Adjustable Shelves (C), remove the #6 x 1/2" Undercut Screws (T) and the Shelf (C). Position the Shelf Brackets (S) to the desired locations, replace the shelf and insert the screws. See Figures 2 and 2a.




Fig. 2a

Fig. 2

# 1152GBCH Cascade 1-Door Chest

## Assembly Instructions

3. **Tipping restraint:** Locate two studs in the wall behind the unit. Attach a Clip (T1) to one wall stud with two #8 x 2" Black Screws (T3). See Figure 3a. Attach a second clip to the unit with two #8 x 1" Pan Head Screws (T4). See Figure 3b. Connect the two clips with the Nylon Restraint Strap (T2). Pull the Nylon Restraint Strap (T2) tight so there is no slack. See Figures 3c and 3d. Repeat this procedure to attach the second tipping restraint. If you cannot locate two studs, purchase the proper wall attachment hardware for your type of wall and secure the unit.

