

Model #


4861AFGMS

Ambierle 60"W

Media Console

Glazed Millstone finish

Assembly Instructions



Congratulations!

This fine piece of furniture will make a gorgeous addition to your home. For the best results, read the Assembly Instructions before you begin your project.

IMPORTANT NOTES:

- For normal household use only. *Not* recommended for commercial use.
- Do not climb, sit or stand on this piece of furniture.
- Do not overload the drawers or shelves.
- Unload items before you move this unit.
- Before you load or move this unit, tighten all screws and supports.



- Handle the glass plates with care. Glass is fragile.
- Before you begin your project, completely read the Assembly Instructions.
- Store this item: 1- in its box; 2- in a dry place; 3- in temperatures that range from 40°F to 90°F (not on a cold and possibly damp cement floor).
- Periodically inspect your furniture for any loose glue joints, screws or any other problem that might affect the stability of your furniture. Tighten or repair as needed.
- This assembly requires two people.

! WARNING

Serious or fatal crushing injuries can occur from furniture tip-over. Use of tip-over restraints may only reduce but not eliminate the risk of tip-over.

To help prevent tip-over:

- Place heaviest items in the bottom drawers.
- Unless specifically designed to accommodate, do not set TVs or other heavy objects on top of this product.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time.

Warning: At least one tipping restraint kit was included with your piece of Whittier Wood Furniture. When you receive your furniture, be sure to find and properly install the tipping restraint(s). If you cannot locate the restraint(s), please contact us immediately for replacement.

Notice to California Customers

California Prop 65 requires consumer goods to be labeled if any one of 850+ different chemicals or substances, including wood dust, is present even in trace amounts. Drilling, sawing, sanding or machining wood products generates wood dust, a substance known to the State of California to cause cancer. **Warning:** This product contains a chemical or substance known to the State of California to cause cancer, birth defects or other reproductive harm. *California Health and Safety Code Section 25249.6*

DESIGN SUBJECT TO CHANGE WITHOUT NOTICE.



CALL US FIRST! Do not return this item to the store

Service Policy: We will replace any part that is defective, missing or damaged during assembly. For a replacement part, directly contact Whittier Wood Products customer service department by phone, fax, mail or email.

Hours: Our friendly customer service staff can be reached Monday-Friday 7:00 a.m. to 5:00 p.m. (Pacific Time). You may leave a message 24 hours a day, seven days a week.

To Order: Provide the finish and furniture model number (upper portion of this page), the part letter, production code, quantity needed, reason for replacement and your full name, address and telephone number.

Parts ship from our Eugene, Oregon factory within one or two business days from the time we receive your request. Please allow five to ten business days for delivery.

800-653-3336 • Outside the U.S. or Canada: 541-687-0213 • Fax: 541-687-2060
www.whittierwood.com • P.O. Box 2827 • Eugene, Oregon 97402, U.S.A.



P.O. Box 2827
Eugene, OR 97402 USA

Production Code:




VN

03/14

4861AFGMS Ambierle 60"W Media Console



Parts List

Please identify the parts and check that quantities received match those on this list.
If you need to replace a part, refer to the following letter and part name.

Part	Description		Quantity
A	Top (attached)		1
B	Case		1
C	Adjustable Shelf (installed)		2
D	Removable Back (installed)		2
E	Glass Door Frame (installed)		2
F	Door Glass (attached)		2
G	Door Glass Support Rail (attached)		4
H	Door Glass Support Stile (attached)		4
I	Drawer Box (inserted)		2
J	Drawer Face (installed)		2
K	Drawer Slides (pre-installed sets)		2
L	#6 x 5/8" Undercut Screw AB (inserted)		28
M	#6 x 3/4" Philtruss Screw (inserted)		12
N	#6 x 1/2" Undercut Screw AB (inserted)		8
O	#6 x 3/4" Flat Head Screw (inserted)		16
P	#6 x 1/2" Philtruss Screw (inserted)		12
Q	#6 x 5/8" Philtruss Screw (inserted)		16
R	#8 x 1-3/8" Lo-Profile Screw (inserted)		15
S	#8 x 1" Pan Head Screw (inserted)		5
T	#8 x 1-1/4" Pan Head Screw (inserted)		9
U	#8 x 7/8" Black Lo-Profile Screw (inserted)		8
V	#8 x 1-1/4" Black Screw (inserted)		6
W	Hinge (attached)		4
X	Drawer Stop (attached)		4

4861AFGMS Ambierle 60"W Media Console

Parts List

Part	Description	Quantity
Y	Insert Nut (inserted) 	4
ZA	Turn Button (attached) 	4
ZB	Tuscan Magnetic Lock & Plate (pre-installed sets) 	2
ZC	Adjustable Glide (installed) 	4
ZD	Shelf Bracket (installed) 	8
ZE	Knob (attached) 	4
ZF	#8 x 1-1/4" Machine Screw (installed) 	4
TR	Media Zip-Tie Tipping Restraint	1 set

4861AFGMS Ambierle 60"W Media Console

Assembly Instructions

Tool Required: Phillips Screwdriver, Pencil.

1. Place the unit at its final destination. Rotate the Adjustable Glides (ZC) on the bottoms of the legs until the unit is level. See Figure 1.





Fig. 1

2. To insert your media components and access wires more easily, you may want to remove the Removable Backs (D). To do so, unlock the Turn Buttons (ZA) as shown in Figures 2 and 2b. Slide the Backs away and place them off to the side. After installing the components, slide the Backs (D) behind the Drawer Stops (X) and lock the Turn Buttons. See Figures 2, 2a, 2b, 2c.




4861AFGMS Ambierle 60"W Media Console

Assembly Instructions

3. To move the Adjustable Shelf (C), remove the #6 x 1/2" Undercut Screws (N) and the Shelves (C). Insert the Shelf Brackets (ZD) into the desired slots, place the shelves on top of the brackets and insert the screws. See Figures 3 and 3a.

Doors removed for illustration purposes.



Continued on Page 6

4861AFGMS Ambierle 60"W Media Console

Assembly Instructions

- Position the unit at the desired location. Locate one stud in the wall behind the unit. A strong small magnet is helpful to locate the studs in the wall. The magnet will help you find the nails or screws used to attach the wall to the studs. When you have found a screw you have found a stud. Studs are usually 16" on center. Choose the wooden stud which is closest to the center of your case. Attach a Clip (T1) to the wall stud with #8 x 2" Black Screws (T3). See Figure 4a. The clip attached to the furniture must penetrate solid wood such as a frame member behind the back, the top, an apron or a leg. Do not attach where it will be screwed only into the thin back panel. See the instruction for your individual furniture piece for recommended attachment point. Attach a second clip to the unit with #6 x 5/8" Philtruss Screw (T5). See Figure 4b. Connect the two clips with the Nylon Zip-Tie (T2). **Pull the Nylon Zip-Tie (T2) tight so there is no slack.** See Figures 4c and 4d. We have included an extra Nylon Zip-Tie in your kit; if you should need to move your furniture cut the Zip-Tie that you are using and replace with the extra Zip-Tie when the furniture is back in place.

The screws attaching your furniture to the wall must be inserted into a wall stud. Do not attempt to use wall anchors.

